

BACK TO SCHOOL

LAMP PROMOTION

SPONSORED BY OSRAM 

Brand	Model
3M	DMS-800
3M	DMS-810
3M	DMS-815
3M	DMS-865
3M	DMS-878
3M	S800
3M	S815
ACER	H5350
ACER	H6510BD
ACER	P1500
ACER	U5213
ACER	U5313W
ACER	X110
ACER	X110P
ACER	X1160
ACER	X1160P
ACER	X1160PZ
ACER	X1160Z
ACER	X1161
ACER	X1161P
ACER	X1260
ACER	X1260P
ACER	X1261
ACER	X1261P
ACER	XD1160
ACER	XD1160Z
BARCO	RLM W6
BENQ	MP735
BENQ	MX662
BENQ	MX720
BENQ	PU9530
BENQ	PW9250
BENQ	PW9500
BENQ	PW9520

BENQ	PX9510
BENQ	PX9600
BENQ	W1070
BENQ	W1080ST
CANON	LV-7585
CHRISTIE	LX120
CHRISTIE	LX650
CHRISTIE	VIVID LX650
CHRISTIE	VIVID LX900
DELL	2400MP
DELL	S510
DELL	S510Wi
DELL	S520
DELL	S520Wi
DIGITAL PROJECTION	EON WXGA 6000
DIGITAL PROJECTION	EON XGA 6000
DIGITAL PROJECTION	EVISION 7000
DIGITAL PROJECTION	EVISION WUXGA 6800
DIGITAL PROJECTION	EVISION WXGA 1
DIGITAL PROJECTION	EVISION WXGA 600
DIGITAL PROJECTION	EVISION WXGA 6000
DIGITAL PROJECTION	EVISION WXGA 6500
DIGITAL PROJECTION	EVISION XGA 6500
DONGWON	DLP-1200
DONGWON	DLP-600S
DONGWON	DLP-640N
DONGWON	DLP-640S
DONGWON	DLP-765S
DONGWON	DVM-D60M
DONGWON	DVM-D60MJ
DONGWON	DVM-D60MN
DONGWON	DVM-F75M
DONGWON	DVM-L60M
DUKANE	I-PRO 8404
DUKANE	I-PRO 8406
EIKI	EIP-5000 (Left lamp)
EIKI	EIP-5000 (Right lamp)
EIKI	EIP-5000L (Left lamp)
EIKI	EIP-5000L (Right lamp)
EIKI	EIP-WSS3100
EIKI	LC-X80
EIKI	LC-XB40
EIKI	LC-XB40N
EIKI	LC-XT4
EPSON	BrightLink 425Wi
EPSON	BrightLink 430i
EPSON	BrightLink 435Wi
EPSON	BrightLink 436Wi
EPSON	BrightLink 450Wi

EPSON	BrightLink 455Wi
EPSON	BrightLink 455Wi-T
EPSON	CINEMA 550
EPSON	EB-1830
EPSON	EB-1900
EPSON	EB-1910
EPSON	EB-1915
EPSON	EB-1920W
EPSON	EB-1925W
EPSON	EB-1940W
EPSON	EB-1945W
EPSON	EB-1950
EPSON	EB-1955
EPSON	EB-1960
EPSON	EB-1965
EPSON	EB-1970W
EPSON	EB-1975W
EPSON	EB-1980WU
EPSON	EB-1985WU
EPSON	EB-410W
EPSON	EB-410WE
EPSON	EB-420
EPSON	EB-425W
EPSON	EB-430
EPSON	EB-435W
EPSON	EB-440W
EPSON	EB-450W
EPSON	EB-450Wi
EPSON	EB-4550
EPSON	EB-455Wi
EPSON	EB-460
EPSON	EB-460i
EPSON	EB-4650
EPSON	EB-465i
EPSON	EB-4750W
EPSON	EB-4850WU
EPSON	EB-4950WU
EPSON	EB-824
EPSON	EB-825
EPSON	EB-826W
EPSON	EB-84
EPSON	EB-84e
EPSON	EB-84he
EPSON	EB-84l
EPSON	EB-85
EPSON	EB-905
EPSON	EB-915W
EPSON	EB-925
EPSON	EB-93

EPSON	EB-93e
EPSON	EB-945
EPSON	EB-95
EPSON	EB-955W
EPSON	EB-965
EPSON	EB-96W
EPSON	EB-98
EPSON	EB-S02
EPSON	EB-S03
EPSON	EB-S10
EPSON	EB-S11
EPSON	EB-S12
EPSON	EB-S17
EPSON	EB-S18
EPSON	EB-S6
EPSON	EB-S62
EPSON	EB-S6LU
EPSON	EB-S7
EPSON	EB-S72
EPSON	EB-S8
EPSON	EB-S82
EPSON	EB-S9
EPSON	EB-S92
EPSON	EB-SXW03
EPSON	EB-SXW11
EPSON	EB-SXW12
EPSON	EB-SXW18
EPSON	EB-TW420
EPSON	EB-W02
EPSON	EB-W10
EPSON	EB-W12
EPSON	EB-W16
EPSON	EB-W16SK
EPSON	EB-W18
EPSON	EB-W22
EPSON	EB-W28
EPSON	EB-W6
EPSON	EB-W7
EPSON	EB-W8
EPSON	EB-W9
EPSON	EB-X02
EPSON	EB-X03
EPSON	EB-X10
EPSON	EB-X11
EPSON	EB-X11H
EPSON	EB-X12
EPSON	EB-X14
EPSON	EB-X15
EPSON	EB-X18

EPSON	EB-X20
EPSON	EB-X24
EPSON	EB-X25
EPSON	EB-X6
EPSON	EB-X62
EPSON	EB-X6LU
EPSON	EB-X7
EPSON	EB-X72
EPSON	EB-X8
EPSON	EB-X8e
EPSON	EB-X9
EPSON	EB-X92
EPSON	EH-TW2800
EPSON	EH-TW2900
EPSON	EH-TW3000
EPSON	EH-TW3200
EPSON	EH-TW3500
EPSON	EH-TW3600
EPSON	EH-TW3800
EPSON	EH-TW4000
EPSON	EH-TW420
EPSON	EH-TW4400
EPSON	EH-TW450
EPSON	EH-TW4500
EPSON	EH-TW480
EPSON	EH-TW490
EPSON	EH-TW5000
EPSON	EH-TW5200
EPSON	EH-TW550
EPSON	EH-TW5500
EPSON	EH-TW570
EPSON	EH-TW5800
EPSON	EH-TW8500
EPSON	EMP-1700
EPSON	EMP-1705
EPSON	EMP-1707
EPSON	EMP-1710
EPSON	EMP-1715
EPSON	EMP-1717
EPSON	EMP-1915
EPSON	EMP-260
EPSON	EMP-280
EPSON	EMP-400
EPSON	EMP-400W
EPSON	EMP-400WE
EPSON	EMP-410W
EPSON	EMP-62
EPSON	EMP-62C
EPSON	EMP-63

EPSON	EMP-76C
EPSON	EMP-77C
EPSON	EMP-82
EPSON	EMP-822
EPSON	EMP-822H
EPSON	EMP-825
EPSON	EMP-83
EPSON	EMP-83C
EPSON	EMP-83H
EPSON	EMP-83HE
EPSON	EMP-84he
EPSON	EMP-S4
EPSON	EMP-S42
EPSON	EMP-S5
EPSON	EMP-S52
EPSON	EMP-S6
EPSON	EMP-TW1000
EPSON	EMP-TW2000
EPSON	EMP-TW3800
EPSON	EMP-TW5000
EPSON	EMP-TW520
EPSON	EMP-TW5500
EPSON	EMP-TW600
EPSON	EMP-TW620
EPSON	EMP-TW680
EPSON	EMP-TW700
EPSON	EMP-TW980
EPSON	EMP-X3
EPSON	EMP-X5
EPSON	EMP-X52
EPSON	EMP-X56
EPSON	EMP-X6
EPSON	EX100
EPSON	EX21
EPSON	EX30
EPSON	EX31
EPSON	EX3200
EPSON	EX3210
EPSON	EX3212
EPSON	EX3220
EPSON	EX50
EPSON	EX51
EPSON	EX5200
EPSON	EX5210
EPSON	EX5220
EPSON	EX5230
EPSON	EX6210
EPSON	EX6220
EPSON	EX70

EPSON	EX71
EPSON	EX7200
EPSON	EX7210
EPSON	EX7220
EPSON	EX7230
EPSON	EX7235
EPSON	EX90
EPSON	H281B
EPSON	H283A
EPSON	H283B
EPSON	H283C
EPSON	H284A
EPSON	H284B
EPSON	H284C
EPSON	H285C
EPSON	H291A
EPSON	H291B
EPSON	H291F
EPSON	H292A
EPSON	H293A
EPSON	H293B
EPSON	H294B
EPSON	H295A
EPSON	H296A
EPSON	H297A
EPSON	H309A
EPSON	H309C
EPSON	H310C
EPSON	H311B
EPSON	H311C
EPSON	H312A
EPSON	H312B
EPSON	H312C
EPSON	H313C
EPSON	H314A
EPSON	H314B
EPSON	H314C
EPSON	H315B
EPSON	H315C
EPSON	H316C
EPSON	H318A
EPSON	H326B
EPSON	H326C
EPSON	H327A
EPSON	H327C
EPSON	H328A
EPSON	H328B
EPSON	H328C
EPSON	H330A

EPSON	H330B
EPSON	H330C
EPSON	H331A
EPSON	H331C
EPSON	H336A
EPSON	H336F
EPSON	H337A
EPSON	H338A
EPSON	H341C
EPSON	H343A
EPSON	H353A
EPSON	H353B
EPSON	H353C
EPSON	H354C
EPSON	H355B
EPSON	H355C
EPSON	H356C
EPSON	H357C
EPSON	H367A
EPSON	H367B
EPSON	H367C
EPSON	H368A
EPSON	H368C
EPSON	H369A
EPSON	H370C
EPSON	H371A
EPSON	H373A
EPSON	H373B
EPSON	H373F
EPSON	H374B
EPSON	H375A
EPSON	H375B
EPSON	H376B
EPSON	H381A
EPSON	H382A
EPSON	H383A
EPSON	H384A
EPSON	H387A
EPSON	H387B
EPSON	H387C
EPSON	H388A
EPSON	H388B
EPSON	H388C
EPSON	H389A
EPSON	H391A
EPSON	H416A
EPSON	H419A
EPSON	H420A
EPSON	H428A

EPSON	H429A
EPSON	H431A
EPSON	H432A
EPSON	H433A
EPSON	H435B
EPSON	H435C
EPSON	H436A
EPSON	H449A
EPSON	H471B
EPSON	H518A
EPSON	H534B
EPSON	H555B
EPSON	HOME CINEMA 1080
EPSON	MG-50
EPSON	MG-850HD
EPSON	PowerLite 1220
EPSON	PowerLite 1221
EPSON	PowerLite 1222
EPSON	PowerLite 1260
EPSON	PowerLite 1261W
EPSON	PowerLite 1262W
EPSON	PowerLite 1263W
EPSON	PowerLite 1284
EPSON	PowerLite 1700c
EPSON	PowerLite 1705c
EPSON	PowerLite 1710c
EPSON	PowerLite 1715c
EPSON	PowerLite 1830
EPSON	PowerLite 1835
EPSON	PowerLite 1915
EPSON	PowerLite 1925W
EPSON	PowerLite 1940W
EPSON	PowerLite 1945W
EPSON	PowerLite 1950
EPSON	PowerLite 1955
EPSON	PowerLite 1960
EPSON	PowerLite 1965
EPSON	PowerLite 1975W
EPSON	PowerLite 1980WU
EPSON	PowerLite 1985WU
EPSON	PowerLite 400W
EPSON	PowerLite 420
EPSON	PowerLite 425W
EPSON	PowerLite 430
EPSON	PowerLite 435W
EPSON	PowerLite 450W
EPSON	PowerLite 460
EPSON	PowerLite 4650
EPSON	PowerLite 4750W

EPSON	PowerLite 4770W
EPSON	PowerLite 4855WU
EPSON	PowerLite 62C
EPSON	PowerLite 76C
EPSON	PowerLite 77c
EPSON	PowerLite 78
EPSON	PowerLite 79
EPSON	PowerLite 822p
EPSON	PowerLite 825
EPSON	PowerLite 825+
EPSON	PowerLite 826W
EPSON	PowerLite 826W+
EPSON	PowerLite 82C
EPSON	PowerLite 83+
EPSON	PowerLite 83c
EPSON	PowerLite 84
EPSON	PowerLite 84+
EPSON	PowerLite 85
EPSON	PowerLite 85+
EPSON	PowerLite 905
EPSON	PowerLite 915W
EPSON	PowerLite 92
EPSON	PowerLite 93
EPSON	PowerLite 93+
EPSON	PowerLite 95
EPSON	PowerLite 955W
EPSON	PowerLite 965
EPSON	PowerLite 96W
EPSON	PowerLite 97
EPSON	PowerLite 9700UB
EPSON	PowerLite 98
EPSON	PowerLite 99W
EPSON	PowerLite D6150
EPSON	PowerLite G5910
EPSON	PowerLite HC 1080
EPSON	PowerLite HC 1080UB
EPSON	PowerLite HC 1440
EPSON	PowerLite HC 2000
EPSON	PowerLite HC 2030
EPSON	PowerLite HC 400
EPSON	PowerLite HC 500
EPSON	PowerLite HC 600
EPSON	PowerLite HC 6100
EPSON	PowerLite HC 6500UB
EPSON	PowerLite HC 700
EPSON	PowerLite HC 705HD
EPSON	PowerLite HC 707
EPSON	PowerLite HC 710HD
EPSON	PowerLite HC 720

EPSON	PowerLite HC 725HD
EPSON	PowerLite HC 730HD
EPSON	PowerLite HC 750HD
EPSON	PowerLite HC 8100
EPSON	PowerLite HC 8345
EPSON	PowerLite HC 8350
EPSON	PowerLite HC 8500UB
EPSON	PowerLite HC 8700UB
EPSON	PowerLite PC 1080
EPSON	PowerLite PC 1080UB
EPSON	PowerLite PC 1985
EPSON	PowerLite PC 7100
EPSON	PowerLite PC 7500UB
EPSON	PowerLite PC 800
EPSON	PowerLite PC 810
EPSON	PowerLite PC 9100
EPSON	PowerLite PC 9350
EPSON	PowerLite PC 9500UB
EPSON	PowerLite PC 9700UB
EPSON	PowerLite S10+
EPSON	PowerLite S11
EPSON	PowerLite S12
EPSON	PowerLite S17
EPSON	PowerLite S18+
EPSON	PowerLite S4
EPSON	PowerLite S5
EPSON	PowerLite S6
EPSON	PowerLite S7
EPSON	PowerLite S8+
EPSON	PowerLite S9
EPSON	PowerLite W15+
EPSON	PowerLite W16
EPSON	PowerLite W16SK
EPSON	PowerLite W17
EPSON	PowerLite W18+
EPSON	PowerLite W6
EPSON	PowerLite W7
EPSON	PowerLite X12
EPSON	PowerLite X14+
EPSON	PowerLite X15
EPSON	PowerLite X17
EPSON	PowerLite X24+
EPSON	PowerLite X9
EPSON	VS200
EPSON	VS210
EPSON	VS220
EPSON	VS230
EPSON	VS310
EPSON	VS315W

EPSON	VS320
EPSON	VS330
EPSON	VS335W
EPSON	VS400
GEHA	C 224
INFOCUS	IN112
INFOCUS	IN112A
INFOCUS	IN114
INFOCUS	IN114A
INFOCUS	IN114ST
INFOCUS	IN114STa
INFOCUS	IN116
INFOCUS	IN116A
INFOCUS	IN118HDa
INFOCUS	IN118HDSTA
INFOCUS	IN122
INFOCUS	IN122A
INFOCUS	IN124
INFOCUS	IN124A
INFOCUS	IN124ST
INFOCUS	IN124STA
INFOCUS	IN125
INFOCUS	IN126
INFOCUS	IN126A
INFOCUS	IN126ST
INFOCUS	IN126STA
INFOCUS	IN2124
INFOCUS	IN2124A
INFOCUS	IN2126
INFOCUS	IN2126A
INFOCUS	IN2128HDa
INFOCUS	IN3118HD
INFOCUS	IN3124
INFOCUS	IN3126
INFOCUS	IN3128HD
INFOCUS	LPX15
INFOCUS	LPX6
INFOCUS	LPX7
INFOCUS	LPX9
INFOCUS	T150
INFOCUS	X15
INFOCUS	X20
INFOCUS	X21
INFOCUS	X6
INFOCUS	X7
INFOCUS	X9
MITSUBISHI	EX51U
MITSUBISHI	EX52U
MITSUBISHI	EX53U

mitsubishi	FD630U
mitsubishi	FD730U
mitsubishi	GS316
mitsubishi	GX318
mitsubishi	HC3200
mitsubishi	HC3800
mitsubishi	HC3900
mitsubishi	HC4000
mitsubishi	SD220U
mitsubishi	SD510U
mitsubishi	UD740U
mitsubishi	WD380U-EST
mitsubishi	WD385U-EST
mitsubishi	WD390U-EST (M)
mitsubishi	WD500UST
mitsubishi	WD510U
mitsubishi	WD570
mitsubishi	WD620U
mitsubishi	WD720U
mitsubishi	XD221U
mitsubishi	XD250U
mitsubishi	XD250UST
mitsubishi	XD280U
mitsubishi	XD360-EST
mitsubishi	XD365-EST
mitsubishi	XD500ST
mitsubishi	XD500U
mitsubishi	XD500UST
mitsubishi	XD510
mitsubishi	XD510U
mitsubishi	XD520U
mitsubishi	XD530U
mitsubishi	XD550U
mitsubishi	XD560U
mitsubishi	XD590U
mitsubishi	XD600U
mitsubishi	XD700U
NEC	NP100
NEC	NP200
NEC	NP4000
NEC	NP4001
NEC	NP4100
NEC	NP4100W
NEC	U250X
NEC	U260W
OPTOMA	DH1010
OPTOMA	DS327
OPTOMA	DS329
OPTOMA	DW531ST

OPTOMA	DX327
OPTOMA	DX329
OPTOMA	DX655
OPTOMA	EH1020
OPTOMA	EH1060
OPTOMA	EH1060i
OPTOMA	ES523ST
OPTOMA	ES550
OPTOMA	ES551
OPTOMA	EW533ST
OPTOMA	EW615
OPTOMA	EW631
OPTOMA	EX523ST
OPTOMA	EX540
OPTOMA	EX540i
OPTOMA	EX542
OPTOMA	EX542i
OPTOMA	EX550
OPTOMA	EX550ST
OPTOMA	EX551
OPTOMA	EX612
OPTOMA	EX615
OPTOMA	EX631
OPTOMA	EX779
OPTOMA	EX779i
OPTOMA	FW5200
OPTOMA	FX5200
OPTOMA	GT360
OPTOMA	GT700
OPTOMA	GT720
OPTOMA	GT750
OPTOMA	GT750E
OPTOMA	GT750ECA
OPTOMA	GT750-XL
OPTOMA	HD180
OPTOMA	HD20
OPTOMA	HD200X
OPTOMA	HD200X-LV
OPTOMA	HD20-LV
OPTOMA	HD22
OPTOMA	HD2200
OPTOMA	HD23
OPTOMA	HD230X
OPTOMA	HT1081
OPTOMA	OP300W
OPTOMA	OPX3200
OPTOMA	PRO180ST
OPTOMA	PRO450W
OPTOMA	PRO800P

OPTOMA	S29
OPTOMA	TH1020
OPTOMA	TH1060
OPTOMA	TW615-3D
OPTOMA	TW615-GOV
OPTOMA	TX540
OPTOMA	TX542
OPTOMA	TX612
OPTOMA	TX615
OPTOMA	TX615-3D
OPTOMA	TX615-GOV
OPTOMA	TX779
OPTOMA	W307UST
OPTOMA	W307USTi
OPTOMA	W317UST
OPTOMA	X29i
OPTOMA	X307UST
OPTOMA	X307USTi
PANASONIC	PT-CW330
PANASONIC	PT-CW331R
PANASONIC	PT-CX300
PANASONIC	PT-CX301R
PROMETHEAN	EST-P1
PROMETHEAN	PRM25
PROMETHEAN	PRM32
PROMETHEAN	PRM35
SAGEM	MDP 2000S
SANYO	PDG-DSU20
SANYO	PDG-DSU20B
SANYO	PDG-DSU20N
SANYO	PDG-DSU21
SANYO	PDG-DWT50
SANYO	PDG-DWT50L
SANYO	PDG-DXT10
SANYO	PDG-DXT10L
SANYO	PLC-XF46
SANYO	PLC-XF46E
SANYO	PLC-XP100
SANYO	PLC-XP100L
SANYO	PLC-XU100
SANYO	PLC-XU110
SANYO	PLV-HD2000
SHARP	XG-PH70X (Left)
SHARP	XG-PH70X (Right)
SMARTBOARD	685iX
SMARTBOARD	885iX
SMARTBOARD	SBP-10X
SMARTBOARD	SBP-15X
SMARTBOARD	SBP-20W

SMARTBOARD	SLR40Wi
SMARTBOARD	SLR60wi2
SMARTBOARD	ST230i
SMARTBOARD	Unifi 35
SMARTBOARD	Unifi 55
SMARTBOARD	Unifi 55w
SMARTBOARD	Unifi 65
SMARTBOARD	Unifi 65w
SMARTBOARD	Unifi 70
SMARTBOARD	Unifi 70w
SMARTBOARD	Unifi 75
SMARTBOARD	Unifi 75w
SMARTBOARD	UX60
SMARTBOARD	X885ix
TOSHIBA	SP1
TOSHIBA	TDP SP1
TOSHIBA	WX5400
TRIUMPH BOARD	PJ3000iUST-W
TRIUMPH BOARD	PJ3000UST-W
VIEWSONIC	PJ551D
VIEWSONIC	PJ557D
VIEWSONIC	PJD5123
VIEWSONIC	PJD5133
VIEWSONIC	PJD5223
VIEWSONIC	PJD5233
VIEWSONIC	PJD5353
VIEWSONIC	PJD5523W
VIEWSONIC	PJD6243
VIEWSONIC	PJD7820HD
VIEWSONIC	PJD7822HDL
VIEWSONIC	Pro6200
VIVITEK	D-5500
VIVITEK	D-5510
VIVITEK	D-5600
VIVITEK	D-6000
VIVITEK	D-6010
VIVITEK	D-6500
VIVITEK	D-6510
VIVITEK	D-791ST
VIVITEK	D-795WT
VIVITEK	D-851
VIVITEK	D-853W
VIVITEK	D-855ST
VIVITEK	D-856STPB
VIVITEK	D-857WT
VIVITEK	D-858WTPB
VIVITEK	D-925TX
VIVITEK	D-927TW
VIVITEK	D-935VX

VIVITEK
VIVITEK
VIVITEK
VIVITEK

D-952HD
DU-6675
DW-6035
DX-6535